



## Unilux Touch AM Wi-Fi Thermostat



### ① Increasing Set Temperature

To increase the temperature in your suite, touch the up arrow until you reach your desired setting.

### ② Decreasing Set Temperature

To decrease the temperature in your suite, touch the down arrow until you reach your desired setting.



### Selecting Operating Mode

To select your operating mode:

- Touch the operating mode field until you reach your desired setting
- You can select heating, cooling, automatic changeover and off.

# Unilux Touch AM Wi-Fi Thermostat

## Changing Fan Settings

To change your fan setting, touch the fan field until you reach your desired setting.




## Wi-Fi Upgrade Available

Your thermostat can be upgraded to include Wi-Fi capabilities. Adding Wi-Fi to your units allows you to control your comfort from anywhere with a smartphone, tablet or computer using our app, Universe.

For more information on how to add our Wi-Fi program to your vertical fan coil, please contact Unilux VFC Parts & Service.

- Phone: 905.265.2418
- Toll Free: 1.800.397.3680
- Email: [service@uniluxvfc.com](mailto:service@uniluxvfc.com)



BA-19-30075